

ADAM-5000 Series

RS-485 Based Data Acquisition
and Control System

User's Manual

Copyright Notice

This document is copyrighted, 1998, by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd., reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements upon the rights of third parties which may result from its use.

Acknowledgments

ADAM is a trademark of Advantech Co., Ltd.

IBM and PC are trademarks of International Business Machines Corporation.

CE Notification

The ADAM-5000/485 series developed by Advantech Co., Ltd. has passed the CE test for environmental specifications. Test conditions for passing included the equipment being operated within an industrial enclosure, using shielded twisted-pair RS-485 cables and having SFC-6 sleeve core clamps added to the power cable and the RS-485 cable. In order to protect the ADAM-5000/485 system from being damaged by ESD (Electrostatic Discharge) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products, shielded twisted-pair RS-485 cables, and core clamps.

A Message to the Customer...

Advantech Customer Services

Each and every Advantech product is built to the most exacting specifications to ensure reliable performance in the unusual and demanding conditions typical of industrial environments. Whether your new Advantech equipment is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Advantech has come to be known.

Your satisfaction is our number one concern. Here is a guide to Advantech's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

Technical Support

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For most frequently asked questions you can easily find answers in your product documentation. These answers are normally a lot more detailed than the ones we can give over the phone.

So please consult this manual first. If you still can't find the answer, gather all the information or questions that apply to your problem and, with the product close at hand, call your dealer. Our dealers are well trained and ready to give you the support you need to get the most from your Advantech products. In fact, most problems reported are minor and are able to be easily solved over the phone.

In addition, free technical support is available from Advantech engineers every business day. We are always ready to give advice on application requirements or specific information on the installation and operation of any of our products.

Product Warranty

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for one year from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability as a consequence of such events under the terms of this Warranty.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product ever does prove defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered (e.g. type of PC, CPU speed, Advantech products used, other hardware and software used etc.). Note anything abnormal and list any on-screen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
3. If your product is diagnosed as defective, obtain an RMA (return material authorization) number from your dealer. This allows us to process your return more quickly.
4. Carefully pack the defective product, a completely filled-out Repair and Replacement Order Card and a photocopy of dated proof of purchase (such as your sales receipt) in a shippable container. A product returned without dated proof of purchase is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

Table of Contents

Chapter 1 Introduction

1.1	Overview	1-2
1.2	System Configuration	1-3
1.3	A Few Steps to a Successful System	1-3

Chapter 2 Installation Guideline

2.1	General	2-2
	Environmental Specifications	2-2
	Power Requirements	2-2
	Diagnostic Indicators	2-2
	Setting the Network Address Switch	2-3
	Dimensions and Weights	2-4
2.2	Module Installation	2-5
2.3	I/O Slots and I/O Channel Numbering	2-5
2.4	Mounting	2-6
	Panel Mounting	2-6
	DIN Rail Mounting	2-6
2.5	Wiring and Connections	2-7
	DC Power Supply Unit Wiring	2-7
	I/O Modules Wiring	2-8
	RS-485 Port Connection	2-9
	RS-232 Port Connection	2-10

Chapter 3 ADAM-5000/485 System

3.1	Overview	3-2
3.2	Major Features of the ADAM-5000/485 System ..	3-2
	The CPU's Basic Functions	3-2
	Diagnosis	3-3
	3-Way Isolation and Watchdog Timer	3-3
	Remote Software Configuration and Calibration ...	3-3
	Flexible Alarm Setting	3-3
	Connectivity and Programming	3-4
3.3	System Setup	3-5
	A Single System Setup thru the RS-232 Port	3-5
	A Distributed I/O Setup thru the RS-485 Network	3-5
3.4	Technical Specifications of ADAM-5000/485	3-5
	Processor	3-5
	Communication	3-6
	Isolation	3-6
	Diagnosis	3-6
	Basic Function Block Diagram	3-7

Chapter 4 I/O Modules

4.1	RTD Input Module	4-2
	ADAM-5013 3-channel RTD input module	4-2
	Technical specifications of ADAM-5013	4-4
4.2	ADAM-5013 RTD Input Resistance Calibration	4-5
	Calibration Resistances (ADAM-5013)	4-6

4.3	Analog Input Modules	4-7
	ADAM-5017 8-channel Analog Input Module	4-7
	Technical Specifications of ADAM-5017	4-9
	ADAM-5017H 8-channel High Speed Analog Input Module	4-9
	Technical Specifications of ADAM-5017H	4-13
	ADAM-5018 7-channel Thermocouple Input Module	4-14
	Technical Specification for ADAM-5018	4-16
4.4	Analog Output Modules	4-16
	ADAM-5024 4-Channel Analog Output Module	4-16
	Slew Rate	4-17
	Technical specifications of ADAM-5024	4-18
4.5	Analog I/O Modules Calibration	4-19
	Analog Input Module Calibration	4-19
	Calibration Voltage (ADAM-5017/5018)	4-22
	Calibration Voltage (ADAM-5017H)	4-23
	Analog Output Module Calibration	4-24
4.6	Digital Input/Output Modules	4-25
	ADAM-5050 16-channel universal digital I/O module	4-25
	Technical specifications of ADAM-5050	4-28
	ADAM-5051 16-channel digital input module	4-28
	Technical specifications of ADAM-5051	4-29
	ADAM-5052 8-channel isolated digital input module	4-30
	Technical specifications of ADAM-5052	4-31

	ADAM-5056 16-channel digital output module ...	4-31
	Technical specifications of ADAM-5056	4-32
4.7	Relay Output Modules	4-33
	ADAM-5060 Relay output module	4-33
	Technical specifications of ADAM-5060	4-34
	ADAM-5068 Relay output module	4-34
	Technical specifications of ADAM-5068	4-35

Chapter 5 Software Utilities

5.1	ADAM Utility Software	5-2
	Main Menu	5-2
	Setup	5-3
	System Setting	5-4
	Module Setting	5-5
	Output Data	5-5
	Calibration	5-6
	File	5-6
	Terminal	5-6
	Download Procedure: New ADAM-5000/485 Firmware	5-7
	Quit	5-8
5.2	DLL (Dynamic Link Library) Driver	5-8
5.3	DDE (Dynamic Data Exchange) Server	5-9

Chapter 6 Command Set

6.1	Introduction	6-2
6.2	Syntax	6-2
6.3	CPU Command Set	6-4
6.4	ADAM-5013 RTD Input Command Set	6-19
6.5	Analog Input Command Set	6-37
6.6	ADAM-5017H Analog Input Command Set	6-57
6.7	Analog Input Alarm Command Set	6-71
6.8	Analog Output Command Set	6-90
6.9	Digital Input/Output Command Set	6-107

Chapter 7 Troubleshooting

	Diagnosis	7-2
7.1	Hardware Diagnosis	7-2
7.2	Software Diagnosis	7-2
7.3	System Indicators	7-3
	PWR Indicator	7-3
	Incorrect External Power	7-4
	Faulty Power Supply	7-4
	Device or Module causing Power Supply to Shutdown	7-4
	RUN Indicator	7-5
7.4	Communication Problems	7-5
7.5	I/O Module Troubleshooting	7-6
	Some Quick Steps	7-6

Appendix A Quick Start Example

- A.1 System Requirements to Setup an ADAM-5000 System A-2
- A.2 Basic Configuration Hook-up A-5
- A.3 Baud Rate and Checksum A-8
- A.4 A Distributed ADAM-5000 Network System Hook-up A-11

Appendix B Data Formats and I/O Ranges

- B.1 Analog Input Formats B-2
- B.2 Analog Input Ranges - ADAM-5017 and 5018 B-4
- B.3 Analog Input Ranges of ADAM-5017H B-7
- B.4 Analog Output Formats B-8
- B.5 Analog Output Ranges B-8
- B.6 ADAM-5013 RTD Input Format and Ranges B-9

Appendix C RS-485 Network

- C.1 Basic Network Layout C-3
- C.2 Line Termination C-6
- C.3 RS-485 Data Flow Control C-9

Appendix D How to Use the Checksum Feature

- D.1 Checksum Enable/Disable D-2

Table of Figures

Figure 1-1	ADAM-5000 System Configurations	1-3
Figure 2-1	ADAM-5000 Diagnostic indicators	2-3
Figure 2-2	ADAM-5000 Network address DIP switch	2-4
Figure 2-3	Module alignment and installation	2-5
Figure 2-4	ADAM-5000 Panel mounting	2-6
Figure 2-5	ADAM-5000 Rail mounting	2-7
Figure 2-6	ADAM-5000 Wiring and connections	2-8
Figure 3-1	Function block diagram	3-7
Figure 4-1	ADAM-5013 module frontal view	4-2
Figure 4-2	RTD inputs	4-3
Figure 4-3	Applying calibration resistance	4-5
Figure 4-4	ADAM-5017 module frontal view	4-7
Figure 4-5	Millivolt and volt input	4-8
Figure 4-6	Process current input	4-8
Figure 4-7	ADAM-5017H module frontal view	4-10
Figure 4-8	Millivolt and volt input	4-11
Figure 4-9	Process current input	4-11
Figure 4-10	The location for 125 Ohms resistors	4-12
Figure 4-11	ADAM-5018 module frontal view	4-15
Figure 4-12	Thermocouple input	4-15

Figure 4-13	ADAM-5024 module frontal view	4-17
Figure 4-14	Analog output	4-18
Figure 4-15	Applying calibration voltage	4-19
Figure 4-16	Zero Calibration	4-20
Figure 4-17	Span Calibration	4-20
Figure 4-18	Cold Junction Calibration	4-21
Figure 4-19	Output module calibration	4-24
Figure 4-20	Dip switch setting for digital I/O channel	4-26
Figure 4-21	ADAM-5050 module frontal view	4-26
Figure 4-22	Dry contact signal input (ADAM-5050)	4-26
Figure 4-23	Wet contact signal input (ADAM-5050)	4-27
Figure 4-24	Digital output used with SSR (ADAM-5050/5056) ...	4-27
Figure 4-25	ADAM-5051 module frontal view	4-28
Figure 4-26	TTL input (ADAM-5051)	4-29
Figure 4-27	Contact closure input (ADAM-5051)	4-29
Figure 4-28	ADAM-5052 module frontal view	4-30
Figure 4-29	Isolation digital input (ADAM-5052)	4-30
Figure 4-30	ADAM-5056 module frontal view	4-31
Figure 4-31	Digital output used with SSR (ADAM-5050/5056) ...	4-32
Figure 4-32	ADAM-5060 module frontal view	4-33
Figure 4-33	Relay output	4-33
Figure 4-34	ADAM-5068 module frontal view	4-34
Figure 4-35	Relay output	4-35
Figure 5-1	Main screen	5-3
Figure 5-2	Setup options	5-4

Figure 5-3	Zero Calibration	5-6
Figure 5-4	Terminal emulation	5-7
Figure 6-1	Baud rate codes	6-6
Figure 6-2	Analog module error codes	6-18
Figure 6-3	Data format for 8-bit parameters	6-38
Figure 6-4	Data format of 8-bit parameters	6-92
Figure A-1	Power supply connections	A-4
Figure A-2	ADAM-5000 system hook-up and configuration	A-6
Figure A-3	Grounding the INIT* terminal	A-10
Figure A-4	ADAM-5000 network system hook-up	A-11
Figure C-1	Daisy chaining	C-3
Figure C-2	Star structure	C-4
Figure C-3	Random structure	C-5
Figure C-4	ADAM-4000 and ADAM-5000 in a network	C-6
Figure C-5	Signal distortion	C-7
Figure C-6	Termination resistor locations	C-8
Figure C-7	RS-485 data flow control with RTS	C-9

Tables

Table 4-1	Technical specifications of ADAM-5013	4-4
Table 4-2	Calibration resistances of ADAM-5013	4-6
Table 4-3	Technical specifications of ADAM-5017	4-9
Table 4-4	Technical specifications of ADAM-5017H	4-13
Table 4-5	ADAM-5017H input signal ranges	4-14
Table 4-6	Technical specifications of ADAM-5018	4-16
Table 4-7	Technical specifications of ADAM-5024	4-18
Table 4-8	Calibration voltage of ADAM-5017/5018	4-22
Table 4-9	Calibration voltage of ADAM-5017H	4-23
Table 4-10	Technical specifications of ADAM-5050	4-28
Table 4-11	Technical specifications of ADAM-5051	4-29
Table 4-12	Technical specifications of ADAM-5052	4-31
Table 4-13	Technical specifications of ADAM-5056	4-32
Table 4-14	Technical specifications of ADAM-5060	4-34
Table 4-15	Technical specifications of ADAM-5068	4-35